## PLAY22322

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: CAJ348MV jack st (m) 6,3 mm –> 2x CAJ248MV jack mn (m) 6,3 mm.






PC2230



CAJ348MV CAJ248MV



| Code | BK | m |
|---|---|---|
| PLAY22322L03 | | 3 |
| PLAY22322L05 | | 5 |
| PLAY22322L10 | | 10 |

## PLAY22323

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: 2x CAJ248MV jack mn (m) 6,3 mm –> 2x CAJ248MV jack mn (m) 6,3 mm.






PC2230



CAJ248MV CAJ248MV



| Code | BK | m |
|---|---|---|
| PLAY22323L03 | | 3 |
| PLAY22323L05 | | 5 |
| PLAY22323L10 | | 10 |

## PLAY23324

AUDIO

2-pair balanced audio cable: PC2330.

- Connectors: 2x CAJ348MV jack st (m) 6,3 mm –> 2x CAJ348MV jack st (m) 6,3 mm.






PC2330



CAJ348MV CAJ348MV



| Code | BK | m |
|---|---|---|
| PLAY23324L03 | | 3 |
| PLAY23324L05 | | 5 |
| PLAY23324L10 | | 10 |

## PLAY22325

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: 2x CAJ238MV jack mn (m) 6,3 mm –> 2x CAR284MV RCA (m).






PC2330



CAJ238MV CAR284MV



| Code | BK | m |
|---|---|---|
| PLAY22325L03 | | 3 |
| PLAY22325L05 | | 5 |
| PLAY22325L10 | | 10 |

## PLAY22326

AUDIO


2-pair unbalanced audio cable: PC2230.
• Connectors: 2x CAR284MV RCA (m) –> 2x CAR284MV RCA (m).











| Code | BK | m |
|---|---|---|
| PLAY22326L03 | | 3 |
| PLAY22326L05 | | 5 |
| PLAY22326L10 | | 10 |

## PLAY22327


AUDIO

2-pair unbalanced audio cable: PC2235.
• Connectors: 2x RCA (m) –> 2x RCA (m).






| Code | BK | m |
|---|---|---|
| PLAY22327L01 | | 1 |
| PLAY22327L03 | | 3 |
| PLAY22327L05 | | 5 |
| PLAY22327L10 | | 10 |



## PLAY22328


AUDIO

2-pair unbalanced audio cable: PC2235.
• Connectors: jack st (m) 3,5 mm –> 2x RCA (m).






| Code | BK | m |
|---|---|---|
| PLAY22328L01 | | 1 |
| PLAY22328L03 | | 3 |
| PLAY22328L05 | | 5 |
| PLAY22328L10 | | 10 |




## PLAY53313

DMX

DMX cable: HP5330.
• Connectors: CAX304MV XLR (m) 3p –> CAX304FV XLR (f) 3p.





| Code | BK | m |
|---|---|---|
| PLAY53313L01 | | 1 |
| PLAY53313L03 | | 3 |
| PLAY53313L05 | | 5 |
| PLAY53313L010 | | 10 |
| PLAY53313L015 | | 15 |
| PLAY53313L020 | | 20 |


## PLAY53315

DMX

DMX cable: HP5330.
• Connectors: CAX504MV XLR (m) 5p –> CAX504FV XLR (f) 5p.





| Code | BK | m |
|---|---|---|
| PLAY53315L01 | | 1 |
| PLAY53315L03 | | 3 |
| PLAY53315L05 | | 5 |
| PLAY53315L010 | | 10 |
| PLAY53315L015 | | 15 |
| PLAY53315L020 | | 20 |