## TOUR66460

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: MESV10 IEC plug and MEPV10 3p IEC socket.

HC6640

CANC3FXX

CANC3MXX

MESV10

MEPV10

| Code | BK | m |
|---|---|---|
| TOUR66460L05 | | 5 |
| TOUR66460L10 | | 10 |
| TOUR66460L15 | | 15 |
| TOUR66460L20 | | 20 |
| TOUR66460L25 | | 25 |
| TOUR66460L30 | | 30 |

## TOUR66470

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: 911133 Shuko 16A plug and MENAC3FCA Neutrik POWERCON socket.

HC6640

CANC3FXX

CANC3MXX

911133

MENAC3FCA

| Code | BK | m |
|---|---|---|
| TOUR66470L05 | | 5 |
| TOUR66470L10 | | 10 |
| TOUR66470L15 | | 15 |
| TOUR66470L20 | | 20 |
| TOUR66470L25 | | 25 |
| TOUR66470L30 | | 30 |

## TOUR66480

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: 911113 3p 16A plug and MENAC3FCA Neutrik POWERCON socket.

HC6640

CANC3FXX

CANC3MXX

911133

MENAC3FCA

| Code | BK | m |
|---|---|---|
| TOUR66480L05 | | 5 |
| TOUR66480L10 | | 10 |
| TOUR66480L15 | | 15 |
| TOUR66480L20 | | 20 |
| TOUR66480L25 | | 25 |
| TOUR66480L30 | | 30 |

## TOUR66490

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: MENAC3FCB Neutrik powerCON plug and MENAC3FCA Neutrik powerCON socket.

HC6640

CANC3FXX

CANC3MXX

MENAC3FCB

MENAC3FCA

| Code | BK | m |
|---|---|---|
| TOUR66490L05 | | 5 |
| TOUR66490L10 | | 10 |
| TOUR66490L15 | | 15 |
| TOUR66490L20 | | 20 |
| TOUR66490L25 | | 25 |
| TOUR66490L30 | | 30 |

## TOUR76613

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7660.

- Neutrik audio connectors: CANC3MXX XLR-m 3p and CANC3FXX XLR-f 3p
- Power: 911113 3p 16A plug and MENAC3FXW Neutrik powerCON socket.

| Code | m | DMX |
|---|---|---|
| TOUR76613L01BK | 1 | 3-p |
| TOUR76613L02BK | 2 | 3-p |
| TOUR76613L03BK | 3 | 3-p |
| TOUR76613L05BK | 5 | 3-p |
| TOUR76613L10BK | 10 | 3-p |
| TOUR76613L15BK | 15 | 3-p |
| TOUR76613L20BK | 20 | 3-p |
| TOUR76613L25BK | 25 | 3-p |
| TOUR76613L30BK | 30 | 3-p |



## TOUR76615

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC3MXX XLR-m 5p and CANC3FXX XLR-f 5p
- Power: 911113 3p 16A plug and MENAC3MWX Neutrik powerCON socket.

| Code | m | DMX |
|---|---|---|
| TOUR76615L01BK | 1 | 5-p |
| TOUR76615L02BK | 2 | 5-p |
| TOUR76615L03BK | 3 | 5-p |
| TOUR76615L05BK | 5 | 5-p |
| TOUR76615L10BK | 10 | 5-p |
| TOUR76615L15BK | 15 | 5-p |
| TOUR76615L20BK | 20 | 5-p |
| TOUR76615L25BK | 25 | 5-p |
| TOUR76615L30BK | 30 | 5-p |

## TOUR76623

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC3MXX XLR-m 3p and CANC3FXX XLR-f 3p
- Power: MENAC3FXW Neutrik powerCON plug and MENAC3MXW Neutrik powerCON socket.

| Code | m | DMX |
|---|---|---|
| TOUR76623L01BK | 2 | 3-p |
| TOUR76623L02BK | 3 | 3-p |
| TOUR76623L03BK | 4 | 3-p |
| TOUR76623L05BK | 5 | 3-p |
| TOUR76623L10BK | 10 | 3-p |
| TOUR76623L15BK | 15 | 3-p |
| TOUR76623L20BK | 20 | 3-p |
| TOUR76623L25BK | 25 | 3-p |
| TOUR76623L30BK | 30 | 3-p |

## TOUR76625

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC5MXX XLR-m 5p and CANC5FXX XLR-f 5p
- Power: MENAC3FXW Neutrik powerCON plug and MENAC3MXW Neutrik powerCON socket.

| Code | m | DMX |
|---|---|---|
| TOUR76625L01BK | 1 | 5-p |
| TOUR76625L02BK | 2 | 5-p |
| TOUR76625L03BK | 3 | 5-p |
| TOUR76625L05BK | 5 | 5-p |
| TOUR76625L10BK | 10 | 5-p |
| TOUR76625L15BK | 15 | 5-p |
| TOUR76625L20BK | 20 | 5-p |
| TOUR76625L25BK | 25 | 5-p |
| TOUR76625L30BK | 30 | 5-p |